## Self Clinch Flush Head Pin Installation Guide

Punch Or Drill Correct Hole Size.

Place The Fastener In

The Prepared Hole In


**The Panel And Locate** 

The Fastener In The Anvil

Ensure That The Appropriate

Anvil Type Is Used For The Panel Thickness

Like In The Diagrams.




With The Panel Held Level Apply A Squeezing Force Until The Head Is


**Installed Flush To** 

ANVIL


The Panel Do Not Over Squeeze The Fastener
In The Panel. This Could Result In Panel Deformation.



Hole Style Anvil For 1.53mm And Over Panel Thickness



90 Degree Countersunk Hole Style Anvil For 1.52mm Or Less



Do Not Remove Any Extra
Material OR Chanfer The Hole
This Could Result In Improper Installation
Or Reduce Performance

Anvil Dimensions			
Pin	Α	В	С
Dia	+0.05	+0.05	+0.10
3mm	3.10	3.61	4.9
4mm	4.10	4.19	5.44
5mm	5.10	5.61	6.93



Ensure Attention Is Paid To The Minimum Hole
Centreline To Edge Dimension For Each Fastener
Minimum Centreline To Edge Dimensions Shown
For Each Fastener Apply To One Edge Only
If This Distance Is Applied To Multiple Sides There
Will Be Panel Distortion Unless Panel Are Supported
During Installation