

## Hook And Eye Shield Anchors



Eye Bolt



Hook Bolt

Hook And Eye Shield Anchors								
Thread Diameter	Drill Hole Diameter	Clearance Hole Diameter	Minimum Hole Depth	Minimum Embedment Depth	Recommended Load In Any Direction Kn		Minimum Spacing mm	Minimum Edge Distance
					Hook Bolt	Eye Bolt		
M6	12	7	50	40	0.8	1.4	140	70
M8	14	9	55	50	1.6	2.6	150	75
M10	16	12	65	60	2.5	4.2	180	90
M12	20	14	85	80	3.9	6.1	230	120

Loads Are For 30/Nmm<sup>2</sup> Concrete

The Hook And Eye Shield Anchor Are Suitable For Use For Static Loads Only  
Cannot Be Used As Lifting Points Or For Use With Safety Restraint Harnesses

Carbon Steel Bright Zinc Plated And Yellow Passivated Shield Anchor Suitable For Use In  
Concrete - Concrete Blocks - Bricks And Some Natural Stone



1  
Drill Correct Diameter Hole To Correct Depth



2  
Clean Hole By Brushing And Blowing To Remove All Dust And Debris



3  
Insert Shield Hook OR Eye Assembled Into Hole



4  
Tighten Nut To Recommended Torque

INFORMATION AND DRAWINGS PROVIDED ARE FOR REFERENCE ONLY