

Broaching Panel Fastener Installation Guide





2



Punch Or Drill Hole To Specified Diameter (DO NOT Deburr The Hole Seat Fastener Squarely In The Hole

Squeeze Fastener Into Panel Until Shoulder Of The Fastener Makes Contact With The And No Serrations Are Showing

Thread Size	Screw Code	L 2	Α	В
And Pitch	Length	Minimum	+ / - 0.05	+ / - 0.05
M3 x 0.5	40	6.4	8.76	8.2
	62	9.5		
	50	7.9	11.05	9.8
M4 x 0.7	72	11.1		
	94	14.3		
	50	7.9	11.05	10.69
M5 x 0.8	72	11.1		
	94	14.3		
	60	9.5	14.35	12.29
M6 x 1.0	82	12.7		
	94	15.9		