

## Wax Cardboard Cones



Wax Cardboard Cones			
Bolt Length	Length	Internal Diameter At Top	Internal Diameter At Bottom
300	229	70	25
375	305	92	25
400	305	92	25
450	380	108	27
525	457	114	32
600	534	118	32
750	610	132	32

When installing foundation bolting, specifically Holding Down Bolts (Square Square) instances arise where a pocket or void is required around the bolt, to allow for a easier adjustment even after the concrete has been poured and set.

The Cone is simply placed over the inverted bolt, fitting flush with the plate washer or anchorage. The cones can be left in situ until the concrete has set or in the later stages of the concrete setting when the cone can be rotated breaking the bond with the concrete and removed allowing for grouting around the anchor after setting the bolts in their final position.

**INFORMATION AND DRAWINGS PROVIDED ARE FOR REFERENCE ONLY**