

Ankernuts - Rubber Nuts



| Ankerbutts - Rubber Nuts | | | | | | | | | | | | | | | |
|--------------------------|----------|----------|----------|----------|----------|-----------|----------|----------|-----------|-----------|----------|-----------|-----------|-----------|-----------|
| Thread Diameter | M3 | M4 | M4 | M5 | M5 | M5 | M6 | M6 | M6 | M6 | M8 | M8 | M10 | M12 | M12 |
| Hole Diameter | 8 | 8 | 8 | 10 | 10 | 10 | 13 | 13 | 13 | 13 | 16 | 16 | 20 | 24 | 24 |
| Wall Thickness | 2.0-15.0 | 0.4-2.0 | 2.0-15.0 | 0.4-4.0 | 8.0-16.0 | 20.0-30.0 | 0.4-3.0 | 6.0-12.0 | 12.0-25.0 | 25.0-40.0 | 4.0-10.0 | 25.0-35.0 | 25.0-35.0 | 35.0-45.0 | 35.0-45.0 |
| Overall Length | 24 | 13 | 25 | 14 | 25 | 40 | 15 | 25 | 35 | 50 | 25 | 50 | 55 | 75 | 125 |
| Flange thickness | 1 | 1 | 1 | 1 | 1.3 | 1.3 | 1.3 | 1.3 | 1.3 | 1.3 | 1.3 | 1.6 | 1.3 | 1.3 | 1.3 |
| Flange Diameter | 11 | 11 | 11 | 13 | 14 | 14 | 16 | 16 | 16 | 16 | 22 | 20 | 22.5 | 27 | 27 |
| Tightening Torque (Nm) | 1 | 1 | 1 | 1.8 | 1.8 | 1.8 | 4 | 4 | 4 | 4 | 8 | 8 | 10 | 15 | 15 |
| Part Nunbers | LNN03024 | LNN04011 | LNN04024 | LNN05015 | LNN05025 | LNN05040 | LNN06015 | LNN06025 | LNN06035 | LNN06050 | LNN08025 | LNN08050 | LNN10055 | LNN12075 | LNN12125 |

Installation Instructions

- (1) Drill Correct Diameter Hole
- (2) Insert Ankernut Into Drilled Hole
- (3) Position Fixture Over Ankernut And Insert Correct Size Screw
- (4) Tighten Screw To Recommended Torque To Expand Ankernut And Clamp Fixture

| Material | |
|------------------------|-------------------------|
| <i>Sleeve</i> | <i>Synthetic Rubber</i> |
| <i>Threaded Insert</i> | <i>Brass</i> |

INFORMATION AND DRAWINGS PROVIDED ARE FOR REFERENCE ONLY