



Captive Socket Csk Head Screws



Screw The Captive Screw Through
The Screw Hole In The Cover
When The Screw Has Been
Removed From The Frame/Panel



The Screw Will Not Fall From The
Cover Due To The Thread Catching
Against The Screw Hole In The
Cover.
Often Used With A Aaptive Washer

Captive Socket Csk Head Screws							
Diameter-d1	M2	M2.5	M3	M4	M5	M6	
d2 - (+/- 0.12)	1.2	1.7	2	2.8	3.7	4.2	
L2 - (+/- 0.25)	3.5	3.7	4.5	6	7.5	8	
d3 Max	3.8	4.7	5.6	7.5	9.2	11	
h Max	1.2	1.5	1.65	2.2	2.5	3	
A/F	1.3	1.5	2	2.5	3	4	
	Lengths - L1 (+/- 1.5mm)						
	10	10	10	12	12	16	
	To	To	To	To	To	To	
	20	20	40	60	60	60	

Material: A2 Stainless Steel

INFORMATION AND DRAWINGS PROVIDED ARE FOR REFERENCE ONLY