Hollow Wall Anchors And Setting Tool






| Hollow Wall Anchors And Setting Tools | | | | | | | | | |
|---------------------------------------|------|------|-------|-------|------|------|-------|------|-------|
| Thread Diameter | M4 | | | | M5 | | | M6 | |
| Screw Length | 25 | 45 | 50 | 65 | 45 | 60 | 70 | 60 | 70 |
| Hole Diameter | 7 | 7 | 7 | 7 | 10 | 10 | 10 | 13 | 13 |
| Wall Thickness | 0.4 | 8-13 | 16-20 | 22-27 | 5-10 | 5-13 | 17-25 | 7-13 | 16-24 |
| Max. Fixing Thickness | 8 | 16 | 17 | 30 | 17 | 26 | 26 | 30 | 26 |
| Rec Tensile Loads | 0.10 | 0.10 | 0.18 | 0.18 | 0.18 | 0.18 | 0.18 | 0.29 | 0.29 |
| Rec.Shear Strength | 0.14 | 0.14 | 0.23 | 0.23 | 0.23 | 0.23 | 0.23 | 0.34 | 0.34 |




Drill Correct
Diameter Hole



Insert Fixing



Expand Anchor
Using Screw Or
Setting Tool



Remove Screw Position Fixture Re Insert Screw And Tighten